

## § 117.42

(b) If a drawbridge is normally maintained in the fully open to navigation position, but closes to navigation for the passage of pedestrian, vehicular, rail, or other traffic, the drawbridge must be tended unless:

(1) Special operating requirements are established in subpart B of this part for that drawbridge; or

(2) The drawbridge is remotely operated or automated.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

### § 117.42 Remotely operated and automated drawbridges.

(a) Upon written request by the owner of a drawbridge, the District Commander may authorize a drawbridge to operate under an automated system or from a remote location.

(b) If the request is approved, a description of the full operation of the remotely operated or automated drawbridge will be added to subpart B of this part.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

### § 117.47 Clearance gauges.

(a) Clearance gauges are required for drawbridges across navigable waters of the United States discharging into the Atlantic Ocean south of Delaware Bay (including the Lewes and Rehoboth Canal, DE) or into the Gulf of Mexico (including coastal waterways contiguous thereto and tributaries to such waterways and the Lower Atchafalaya River, LA), except the Mississippi River and its tributaries and outlets,

(b) Except for provisions in this part which specify otherwise for particular drawbridges, clearance gauges shall be designed, installed, and maintained according to the provisions of §118.160 of this chapter.

NOTE: Clearance gauge requirements, if any, for drawbridges other than those referred to in this section are listed in Subpart B under the appropriate bridge.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD 84-022, 51 FR 16308, May 2, 1986; CGD 96-026, 61 FR 33664, June 28, 1996]

### § 117.49 Process of violations.

(a) Complaints of alleged violations under this part are submitted to the District Commander of the Coast

## 33 CFR Ch. I (7-1-12 Edition)

Guard District in which the drawbridge is located.

(b) Penalties for violations under this part are assessed and collected under Subpart 1.07 of Part 1 of this chapter.

## Subpart B—Specific Requirements

### § 117.51 General.

The drawbridges in this subpart are listed by the state in which they are located and by the waterway they cross. Waterways are arranged alphabetically by state. The drawbridges listed under a waterway are generally arranged in order from the mouth of the waterway moving upstream. The drawbridges on the Atlantic Intracoastal Waterway are listed from north to south and on the Gulf Intracoastal Waterway from east to west.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

### § 117.55 Posting of requirements.

(a) The owner of each drawbridge under this subpart, other than removable span bridges, must ensure that a sign summarizing the requirements in this subpart applicable to the drawbridge is posted both upstream and downstream of the drawbridge. The requirements to be posted need not include those in Subpart A or §§117.51 through 117.59 of this part.

(b) The signs shall be of sufficient size and so located as to be easily read at any time from an approaching vessel.

(c) If advance notice is required to open the draw, the signs shall also state the name, address, and telephone number of the person to be notified.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

### § 117.59 Special requirements due to hazards.

For the duration of occurrences hazardous to safety or navigation, such as floods, freshets, and damage to the bridge or fender system, the District Commander may require the owner of an operational drawbridge listed in this subpart to have the bridge attended full time and open on signal.

## Coast Guard, DHS

## § 117.123

### ALABAMA

#### § 117.101 Alabama River.

(a) The Alabama & Gulf Coast Railway Drawbridge, mile 105.3, at Coy, shall open on signal if at least 24 hours notice is given.

(b) The draw of the Canadian National/Illinois Central railroad bridge, mile 277 near Montgomery, shall open on signal if at least 24 hours notice is given.

(c) The draw of the CSX Transportation Railroad bridge, mile 293.3 near Montgomery, shall open on signal if at least 24 hours notice is given.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by USCG-2000-7223, 65 FR 40056, June 29, 2000; CGD08-03-018, 68 FR 34303, June 9, 2003; CGD08-04-001, 69 FR 5465, Feb. 5, 2004]

#### § 117.103 Bayou La Batre.

The draw of SR 188 Bridge, mile 2.3, at Bayou La Batre, will open on signal every hour on the hour daily between 4 a.m. and 8 p.m., Monday through Sunday. The bridge need not open for the passage of vessels on the hours of 7 a.m., 3 p.m., and 4 p.m., Monday through Friday. Monday through Friday the draw will open on signal for the passage of vessels at 3:30 p.m. The bridge will remain closed to marine traffic from 8 p.m. to 4 a.m. daily except for emergencies.

[CGD08-05-001, 70 FR 37675, June 30, 2005]

#### § 117.105 Bayou Sara.

The draw of the CSX Transportation Railroad bridge, mile 0.1 near Saraland, shall open on signal; except that, from 6 p.m. to 10 a.m. the draw shall open on signal if at least eight hours notice is given. During periods of severe storms or hurricanes, from the time the National Weather Service sounds an “alert” for the area until the “all clear” is sounded, the draw shall open on signal.

[CGD8-85-12, 50 FR 41685, Oct. 15, 1985]

#### § 117.107 Chattahoochee River.

The draws of the CSX Transportation Railroad bridge, mile 117.1 near Omaha, GA, shall open on signal if at least six hours notice is given.

#### § 117.109 Coosa River.

The draw of the CSX Transportation Railroad bridge, mile 175.0 at Gadsden, shall open on signal if at least six hours notice is given.

#### § 117.113 Tensaw River.

The draw of the CSX Transportation Railroad bridge, mile 15.0 at Hurricane, shall open on signal; except that, from 5 p.m. to 9 a.m., the draw shall open on signal if at least eight hours notice is given. During periods of severe storms or hurricanes, from the time the National Weather Service sounds an “alert” for the area until the “all clear” is sounded, the draw shall open on signal.

[CGD8-85-09, 50 FR 37356, Sept. 13, 1985]

#### § 117.115 Three Mile Creek.

(a) The draw of the US43 bridge, mile 1.0 at Mobile, need not be opened from 7 a.m. to 9 a.m. and from 4:30 p.m. to 6:30 p.m. daily. At all other times, the draw shall open on signal if at least 12 hours notice is given.

(b) The draw of the Norfolk Southern railroad bridge, mile 1.1 at Mobile, shall open on signal if at least five days notice is given.

### ARKANSAS

#### § 117.121 Arkansas River

The draw of the Missouri Pacific Railroad bridge, mile 23.1 near Yancopin, shall open on signal if at least 96 hours notice is given.

#### § 117.123 Arkansas Waterway.

(a) Across the Arkansas Waterway, the draw of the Rob Roy Drawbridge, mile 67.4, at Pine Bluff, Arkansas is maintained in the closed to navigation position and is remotely operated. Any vessel which requires an opening of the draw of this bridge shall establish contact by radiotelephone with the remote drawbridge operator on VHF-FM Channel 12 in Omaha, Nebraska. To establish contact, the vessel shall key the VHF-FM radio microphone four times in five seconds and listen for an acknowledgement tone. The remote drawbridge operator will then establish normal verbal radio communication on VHF-FM Channel 12 and advise the